



NOTES:

1. All piping, fittings, and isolation valves shown by broken lines are provided by others.
2. General plumbing connections are shown for clarity only.
3. Installation of a vacuum breaker is recommended.
4. To allow for expansion and contraction of the FRP media tanks with rigid plumbing, flexible connection fittings should be installed at the control valve.

DIMENSION TABLE	
L= _____	MT= _____
W= _____	
H= _____	

REVISIONS			
NO.	DATE	BY	REMARKS



MFG TWIN PARALLEL WATER FILTER GENERAL ARRANGEMENT			
FRAC. _____	DEC. _____	FILE ID. _____	
DRN. SPL	SCALE _____	SHEET 1 OF 1	
APPD. _____	DRAWING NO. _____		
DATE _____	MFG TWIN PAR		

5-236 03